

IMPORTANT MESSAGE

Be careful to not stretch the belt excessively during installation. In order to maintain speed consistency, they do not have the elasticity of a typical “rubber band”, and will break if stretched too far.

Follow these steps for successful installation with low risk of breakage:

1. Begin by placing the belt on the top groove on the motor pulley and use your left index finger to lightly hold it in the groove while still allowing the belt to slip.



2. Locate the belt along the edge of the platter with your right index finger. Make sure the belt will not get snagged on the center post in the next step.



3. Rotate the platter with your right index finger while holding the belt in place until the rotation is complete and the belt is in position.

