

Thank you for your order!

We appreciate your business. Additional information on your product may be available on our website.



Happy?

Wonderful! We are very glad.
Please share your experience with
us and others. It helps us know
what you like best!

- Review this product at
www.householdessential.com.

Search the item # from the home
page to find the product. Leave your
review under the review tab on the
product's page!

- Follow us on Facebook and
Instagram!

Customer Service

1-800-922-5524 | 1-314-428-5657
info@householdessential.com

Open Mon-Fri at 8:30 am CT.
Closed all national holidays.



©2018 HOUSEHOLD ESSENTIALS, LLC
Hazelwood, MO 63042
www.householdessential.com


Ashwood Coffee Table 8081-1



Parts


Ax1

Top
Panel



Bx1

Lower Shelf
Panel




Cx2

Cross Bar



Dx2

Side
Frame



Ex4

Short
Screw



Fx4

Mid Size
Screw



Gx4

Long
Screw



H


Allen
Wrench



Assembly

1

Attach cross bar (C) to side frame (D) using long screw (G).




NOTE: Finger tighten screws until fully assembled, unless instructed to "tighten fully".

Assembly cont'd

2

Attach metal frame to top panel (A) using short screw (E).



3

Attach lower shelf panel (B) to side frames (D) using mid size screw (F).

Tighten down all screws.

