



INSTALLATION

Step 2: Install back plate covers

1. Position and attach arm with mounting hardware




2. Fasten the covers to the mount




Step 3: Mount the VESA bracket to the TV

1. Align VESA pattern & attach bracket to TV




2. Use appropriate spacers if necessary




Step 4: Secure TV

1. Connect TV to mounting arm




2. Tighten hardware and lock in place



ROY7706B

USER MANUAL



FULL-MOTION WALL MOUNT

Flat Panel TV's

32"-70"

LIMITED LIFETIME WARRANTY

This Royal product carries a LIMITED LIFETIME WARRANTY on both parts and labor. Should your mount fail to operate properly at any time during the warranty period, Royal will repair or replace (at our option) the item barring any indication of misuse or abuse. Freight to a Royal authorized facility is paid by the customer. Return freight is paid by Royal. Warranty registration occurred automatically at the time your order was placed. There is no need to complete or mail in additional paperwork. If you have any questions about the operation or installation of this product, please call our distributor, Skywalker AV Supply at (800) 844-9555 or (636) 272-8025. Skywalker AV Supply hours of operation are from 8am to 5pm CST.

SUPPORT

800.844.9555
techsupport@skywalker.com
skywalker.com



© 2018 Royal Mounts
All Rights Reserved



FULL-MOTION WALL MOUNT

Flat Panel TV's



FULL-MOTION WALL MOUNT

Flat Panel TV's

INTRODUCTION

Congratulations!

The ROY7706B Dual Stud Full-Motion Wall Mount is a great solution for mounting TV's ranging from 32 inches up to 70 inches. This mount can support up to 110 pounds. It has a profile that ranges between 2.8 and 25.6 inches from the wall.






TV SIZE
32" - 70"



110lbs
MAX LOAD
110lbs



2.8" - 25.6 INCH
PROFILE






MAX VESA
400 X 400




BLACK
FINISH

WHAT'S IN THE BOX


Mount Pieces

A (x1)	B (x1)	C (x2)	D (x2)
			
E (x4)	F (x4)	G (x1)	H (x1)
 M6x15			

TV Mounting Hardware

M-A (x4)	M-B (x4)	M-C (x4)	M-D (x4)	M-E (x4)	M-F (x4)	M-G (x8)	M-H (x8)
 M5x14	 M6x14	 M6x30	 M8x30	 M8x50			

Wall Mounting Hardware

W-A (x6)	W-B (x6)	W-C (x6)
		

Tools Needed

- Level
- Pencil
- Drill
- Screwdriver (Phillips)
- Stud Finder *

VESA Patterns


- 200x100
- 300x200
- 400x200
- 400x400
- 200x200
- 300x300
- 400x300

INSTALLATION


Step 1: Mount the back plate to the wall

For Drywall


1. Remove the TV mounting plate




2. Level, mark & drill 1/4" holes for each screw



3. Mount back plate to wall hitting 2 studs




4. Attach the mount arm to the back plate




For Concrete


1. Remove the TV mounting plate



2. Level, mark & drill 1/2" holes for each anchor/screw



3. Mount the back plate to the wall



4. Attach the mount arm to the back plate

