




Saga Sound Series Home Edition

FIG. 1



manual Bluetooth Stereo Adapter

Operation

- To turn the transmitter on, press the Power button for 2-3 seconds. The blue LED will blink.
- To turn the transmitter off, press the Power button for 3-4 seconds. The red LED will blink momentarily to indicate that power is off.
- Plug the 3.5mm stereo jack into a 3.5mm stereo port on the audio source. **NOTE:** For use with a DVD player or TV, use an A/V adapter (not included).
- To pair the transmitter with an audio source, press the Power button (for 5-6 seconds) until the LEDs alternate between blinking red and blinking blue, indicating the transmitter is now in Pairing mode and connecting automatically to the audio device's Bluetooth receiver.
- When the pairing connection is made, only the blue LED will continue to blink. **NOTE:** If the pairing connection isn't made after a minute or so, repeat the above step.
- To activate the built-in microphone, press the Power button. Press it again to resume normal operation.
- The effective range of the transmitter is 20m (approx. 65ft).

Battery Charging

- Plug the travel charger into the AC outlet and then connect the charger into the DC input of the headset and adapter.
- The red indicator will light on. When the battery is full, the red indicator will be off, disconnect the power adapter.
- When the battery is new, it is not fully charged. It takes 4 hours to fully charge the battery.
- Afterwards, it will take nearly 1 hour to fully charge the battery.

