

FOR USE WITH:
Round Crown Staples
or Cable Staples



**For Best Results, use SUREBONDER®
No. 7 Round Crown Staples (3/8" - 9/16")**

****Para mejores resultados, use SUREBONDER®
Grapas redondas corona No. 7 (3/8" - 9/16")**




LOADING INSTRUCTIONS: F1. Squeeze the track release and pull out. Determine length of staple to be used. Leg length should be 2 1/2 times longer than thickness of material being stapled. **F2.** Drop staples into staple chamber with points facing up. Push track closed. Staple gun **WILL NOT** close if loaded incorrectly.

OPERATING INSTRUCTIONS: Place staple gun on area to be stapled. With downward pressure on staple gun, squeeze handle until staple is set. Staple viewer indicates amount of staples left in chamber. To lock handle down for storage: **REMOVE STAPLES**, in one motion, pull handle out, press down and pull out again. Squeeze to release. To adjust the drive, turn wheel forward (+) to increase or backward (-) to decrease staple drive depth.

****INSTRUCCIONES DE CARGA: F1.** Apriete la liberación de la pista y extráigala. Determine la longitud de la grapa que se usará. La longitud de la pierna debe ser 2 1/2 veces más largo que el grosor del material que se grapa. **F2.** Coloque grapas en la cámara de grapas con los puntos hacia arriba. Empujar la pista cerrada. La pistola de grapas **NO** se cerrará si se carga incorrectamente.

INSTRUCCIONES DE OPERACIÓN: Coloque la pistola de grapas en el área a grapar. Con la presión hacia abajo en la pistola de engrapar, apriete el mango hasta que la grapa o la uña estén colocadas. El visor de grapas indica la cantidad de grapas que quedan en la cámara. Para bloquear el asa para el almacenamiento: **RETIRE LAS GRAPAS**, con un solo movimiento, saque la manija, presione hacia abajo y vuelva a sacar. Aprieta para soltar. Para ajustar la unidad, gire la rueda hacia adelante (+) para aumentar o retroceder (-) para disminuir la profundidad de la unidad de grapado.



F1.
Squeeze track release and pull out
Exprimir soltar la pista y extraer



F2.
Load staples with legs pointed up
Cargue grapas / clavos con las piernas hacia arriba